


Gas Levels During Idle to Steady State

WHAT DO THE COMBUSTION GASES MEAN HOW DO I USE THEM WITH A 5 GAS ANALYZER



GREEN is an desired range to be in

Yellow is a acceptable area to be in as long as other gases are not in the RED

Red is an area to use **EXTREME CAUTION** in

The bar chart above shows acceptable exhaust gas ranges during Idle to Steady State for CO2, CO, NOX, HC and O2. These are general that would apply to most engines and base line readings